

# Brewers Supply Group

## 800-374-2739

### Biocloud

Pack size	Application rate
1 kg, 5 kg, 15 kg	Determined by trials

#### Biocloud Prep

A pre-solution of 10% (w/w) Biocloud can be made using high speed stirring in beer or water prior to addition. Biocloud solubilizes and disperses easily in solution. When made in beer a foam will develop on the surface of the beer pre-solution. The foam will dissipate as the concentration of the pre-solution is increased. Following addition to the beer, Biocloud is stable under conventional beer flash and tunnel pasteurization conditions. The desired level of turbidity can be best achieved by experimental use of Biocloud in beer samples prior to production.